



For help visit incyt by LX
incyt.io/support

Copyright 2021 LX Corporation Pty Ltd. All rights reserved.




Water EC Sensor

Quick Start Guide



Product Overview



- 1 EC Sensor
- 2 Connector
- 3 P-clips X 4 and mounting hardware


Preparation

- 1 Unpack the contents of the box.
- 2 This water EC sensor requires a LX Blue Node to function, available for purchase from incyt.io. Follow the instructions provided with the Blue Node to complete setup and activation.


Installation and Mounting

- 3 Choose a location near the water source to be monitored. Install the Blue Node according to it's 'Quick Start Guide', and follow the instructions to plug the connector on the EC sensor into the Blue Node.
- 4 Remove the protective cap on the sensor before installation. Do not touch the end.

- 5 For closed tanks, lower the sensor into the water and fix in position using the supplied P-clips as pictured in the diagram on the right. Ensure the sensor is located more than 15cm away from the walls and base of the tank.



- 6 For open bodies of water, LX suggests purchasing the optional mounting bracket, available from incyt.io. Install using the diagram on the right as a guide, ensuring the sensor is located more than 15cm away from the ground, and is free from any obstructions such as rocks or debris.



- 7 If possible, ensure that data is correctly reporting before leaving the site.



Protect cables from animals by purchasing sheathing from your local hardware store